

APPLY CURING SEALANT TO BOTH SIDES OF RIB PRIOR TO INSTALLING RIB COVER

SPAN-LOK RIB COVER
APPLY CURING SEALANT TO MALE (INSIDE) TRIM

1/8" POP RIVETS

FIELD CUT PANEL RIBS AND BEND OVER EDGE. SEAL OPEN ENDS OF PANEL RIB WITH CURING SEALANT BEFORE INSTALLING RIB COVER.

30# FELT NBA

SPAN-LOK CLIP W/(2) PANCAKE HEAD FASTENERS.

1/4" MIN. CLEARANCE FOR WEEPAGE

PANCAKE HEAD FASTENERS @ 12" OC.

SILL TRIM

OPTIONAL:
NOTCH PANEL RIBS & HEM FLAT OF PANEL



SPAN-LOK hp

RIB COVER

SLHP-7