



NOTE:
 PANELS MUST BE HAND CRIMPED AT
 CLIPS BEFORE MECHANICALLY SEAMING
 PANELS. USE HAND CRIMPING TOOL
 DESIGNED FOR THE SPAN-LOK PANEL.



REV. 11/01/07

SPAN-LOK hp



CLIP &
 THERMAL SPACER

SLHP3D2