

NOTE:
PANELS MUST BE HAND CRIMPED AT
CLIPS BEFORE MECHANICALLY SEAMING
PANELS. USE HAND CRIMPING TOOL
DESIGNED FOR THE SPAN—LOK PANEL.



SPAN-LOK

CLIP & THERMAL SPACER

SL3D2