



INSTALLATION NOTES:

- SWAGE TOP PANEL ONLY
- PANELS MUST BE INSTALLED LEFT TO RIGHT ONLY
- END LAPS OF ADJACENT PANELS MUST BE STAGGERED AT LEAST ONE PURLIN OR A MINIMUM OF 24" TO PREVENT MATERIAL BUILD-UP AT LAPS.



SPAN-LOK hp

PANEL LAP - FLOATING

SL-21