



NOTE:  
FIRST 10" OF PANEL DOWNHILL OF PITCH  
BREAK TRIM WILL NEED TO BE 180° HAND  
CRIMPED TO GET SEAMER ON/OFF.



SPANSEAM



SLOPE TRANSITION  
LO-HI

SPS-18