



RIB COVER

APPLY CURING SEALANT TO BOTH SIDES OF RIB PRIOR TO INSTALLING RIB COVER

RIB COVER

PANEL CLIP

DESIGN SPAN HP PANEL

DESIGN CAUTION:
 ROOF SLOPE TRANSITIONS SUCH AS FASCIAS MAY ESTABLISH AN UNWANTED POINT OF PANEL FIXITY. CONTACT YOUR AEP SPAN REPRESENTATIVE FOR ASSISTANCE.

1/8" RIVET BOTH SIDES

FIELD CUT PANEL RIBS AND BEND OVER EDGE. SEAL OPEN ENDS OF ROOF PANEL RIBS WITH CURING SEALANT BEFORE INSTALLING RIB COVER

DESIGN SPAN HP PANEL

SPECIFIED UNDERLAYMENT (NOT BY AEP-SPAN)

PANEL CLIP (CONTACT AEP-SPAN FOR CLIP LOCATION & SPACING)

SUBSTRATE

PANCAKE HEAD FASTENERS

1/4" MIN. CLEARANCE FOR WEEPAGE

FIELD NOTCH AND HEM 1" (OPTIONAL FACTORY PANEL NOTCH)

DRIP FLASHING (DF009)

SHOULD BE MINIMUM 1/4" GREATER THAN PANEL RIB HEIGHT.

NOTE:
 THE USE OF THIS DETAIL IS NOT RECOMMENDED IN SNOW CLIMATES.



DESIGN SPAN HP

FASCIA TRANSITION / WALL



DS-07