

ROOF JACK

GENERIC PANEL SHOWN

-PIPE PENETRATION

WHEN USING WOOD
SUBSTRATE, WOOD CUTOUT
MUST BE 1" DIAMETER
LARGER THAN ROOF JACK

- STAINLESS STEEL
HOSE CLAMP
(NOT BY AEP-SPAN)

3" MIN -
BOTH SIDES

ROOF JACK (DEKTITE OR EQUIV.)
REFER TO MANUFACTURER'S
INSTRUCTIONS FOR INSTALLATION

UNDERLAYMENT
(NOT BY AEP-SPAN)

FIELD CUT HOLE 1" MIN.
LARGER THAN PIPE.
LOCATE ALL PIPE IN
THE BROAD FLAT OF
THE PANEL.

NOTES:

- 1) PENETRATIONS SHOULD BE CENTERED IN PANELS IF AT ALL POSSIBLE
- 2) SUBSTRATE MUST BE CUT OUT ENOUGH SO THAT ROOF JACK IS ONLY ATTACHED TO ROOF PANEL.

ROOF CURB

SLOPE

CRICKET / UPHILL FLASHING
REFER TO DETAIL #SL-31

ROOF CURB

CURB DOWNHILL FLASHING
REFER TO DETAIL #SL-31

CURB RAKE FLASHING
REFER TO DETAIL #SL-30



SPAN-LOK hp

ROOF PENETRATIONS

SL-29